


LUXEPORT

BaseStation Manual

iportproducts.com/luxeport-support

GET TO KNOW LUXEPORT BASESTATION



- 1) Security Lock
- 2) Articulating Hinge
- 3) Charge Pins
- 4) Removable Security Foot

2



5) Drill Template



6) USB A - USB C Cable



7) USB Power Supply



8) Lock Tool & 4 Screws

BASESTATION SET UP


Step 1

Insert USB cable into bottom of BaseStation and power supply.

Plug power supply into wall.

Step 2

Power adapter can be ran out the back of the Base or down through the table for a clean hidden cable look using a 5/8" drill bit and the provided drill template.



3

NANOPAD CARE

Step 3

Remove plastic covering on the NanoPad before placing on the table.



Step 4

Clean table with provided alcohol pad and ensure surface is dry before placing BaseStation.

If NanoPad loses its suction, clean NanoPad with a damp cloth.




4

ATTACH CASE TO BASESTATION


Step 5

Ensure the Case is properly seated for secure mounting and charging.



Charging begins immediately.

Attach Case in portrait or landscape orientation.



To remove, pull from either left or right side.

5

BASESTATION SECURITY MOUNTING OPTIONS

The LuxePort Case can be securely fastened to the BaseStation for permanent installation. The ability to articulate the viewing angle is maintained, even while secured. The BaseStation can be securely mounted to a desk, wall or VESA via MIS-D, 75 standards.

6

REMOVING SECURITY FOOT


Step 1

Use the provided lock tool to turn both security screws **CLOCKWISE** until full stop.



Step 2

Use a flathead screw driver to remove the security foot using one of the holes near the back of the BaseStation and pry outward.




7

SCREW SECURITY FOOT TO TABLE

Use alignment target to help center the BaseStation. Use provided screws to secure Security Foot to table.

If routing cable into table: Insert drill template onto BaseStation foot. Then mark and drill 5/8" cable hole.

Attach the **FRONT** of the BaseStation first, then set flat on the foot.




8

SECURE BASESTATION TO SECURITY FOOT

Use the provided tool to turn both security screws **COUNTERCLOCKWISE** until full stop.


Place the Case back on the BaseStation in the desired orientation.




9

LOCK THE LUXEPORT CASE TO THE BASESTATION

Use the provided lock tool to turn security screw **COUNTERCLOCKWISE** until stop.



The Case will remain locked to the BaseStation.





USB MODULE (OPTIONAL)

The USB Module can be purchased to charge two additional mobile devices.

The USB Module attaches to the back of the BaseStation and ships with its own power supply to power the LuxePort Case and two additional devices.

The BaseStation with USB Module is great for bedside and kitchen counter applications.

Learn more at iportproducts.com/luxeport





For more help and info
please visit:
iportproducts.com/luxeport

iPort
991 Calle Amanacer
San Clemente, CA 92673
United States of America
+1 949 226 5222



CAUTION: This product contains magnets. Do not place in direct proximity with magnetically sensitive objects such as credit cards or exposed hard drives. Persons with pace makers are not recommended to use this product.



CAUTION: Use products as directed. Unspecified use could result in injury. Warranty can be found at iportproducts.com/warranty

33-7876